

Pit Pad Installation:

1. The Hersey Meters Pit Pad can be installed in most types of meter box lids and vault covers. Check with the manufacturer to determine if a 1-3/4" drilled hole will affect the integrity of the cover. The Hersey Pit Pad is capable of being installed in light traffic areas such as driveway's and parking lots.
 2. Identify the location of the 1-3/4" diameter hole to be drilled. On the top of the lid locate the hole center a minimum of 2" from the outer edge. Underneath the lid locate the center of the hole at least 2" from any ribs that are located under the lid unless the spacing of the ribs allows the nut to be tightened on more than one rib.
 3. If the PitPad is to be located in a shallow box, off set the hole in the box lid so that the split nut (11) avoids contacting the meter register.
 4. To Install the assembly – Insert the Pit Pad flange (9) through the hole from the top of the lid and tighten the flange nut (10) snugly against the underside of the lid. Insert reading pad (8) and secure in place with Split Nut (11)
 5. Excess wire should be coiled so that the lid can be removed without damaging the wire or any connections. The Pit Pad fits lids and covers 1/4" to 2" thick.
-